



Instructions of CC1736 HP M4555MFP/M601/M602N/M602DN/M602X/M603/P4014/4015/4515

UNIVERSAL ENLARGED WASTE TONER HOPPER

T.P.E. CC1736 HP M4555MFP/M601/M602N/M602DN/M602X/M603/P4014/4015/4515 UNIVERSAL ENLARGED WASTE TONER HOPPER



T.P.E. CC1736 HP M4555MFP/M601/M602N/M602DN/M602X/M603/P4014/4015/4515 UNIVERSAL ENLARGED WASTE TONER HOPPER includes the follows:

1. Triton Universal Enlarged Waste Toner Hopper with installed PCR saddles/PCR saddle springs/PCR contact/Metal Agitator Bar/Agitator Lip Seal/Agitator Knob/ IC Chips Holder. All sealing foams and recovery blade are pre-installed as well.
2. OPC drum pin;
3. Drum bearing plate with Gear Set;
4. Mounting screw for Drum bearing plate

The differences between the Waste Toner Hoppers of the OEM HP4014/4015/4515 “A” Cartridge, OEM HP P4015/4515 “X” Cartridge, OEM HP M4555/M601/M602N/M602DN/M602X/M603 “A” and “X” Cartridges means they are not cannot be interchangeable and cannot fit into all those printers. This means specific empty cartridges are required.

A universal cartridge can be made by using the Triton Waste Toner Hopper with any of the following Toner Feed Hoppers

- 1.) Toner Feed Hopper from CC364A and CE390A – this will make a cartridge that can fit into new printers M4555MFP/M601/M602N/M602DN/M602X/M603 and old printers P4014/4015/4515.
- 2.) Toner Feed Hopper from CC364X and CE390X – this will make a cartridge that can fit into new printers M4555MFP/M602N/M602DN/M602X/M603 and old printers P4015/4515.
- 3.) Triton CC1496 HP M4555MFP/M601/M602N/M602DN/M602X/M603/P4014/4015/4515 'X' VERSION HIGH YIELD TONER HOPPER 1,200 GRMS FILL – this will make a cartridge that can fit into new printers M4555MFP/M601/M602N/M602DN/M602X/M603 and old printers P4014/4015/4515.
- 4.) Triton CC1765 HP M602N/M602DN/M602X/M603/P4015/4515 ENLARGED TONER HOPPER – this will make a cartridge that can fit into new printers M602N/M602DN/M602X/M603 and old printers P4015/4515.

Conversion

	<p>Step 1</p> <p>The follow parts are required from the OEM cartridge. Carefully disassemble the OPC Drum; PCR; Wiper Blade and clean them thoroughly.</p> <p>Install the wiper blade as shown and tighten the 2 screws. Remember to lubricate the wiper blade.</p>
	<p>Step 2</p> <p>Install the PCR as shown. If you are re-using an OEM PCR, please make sure it is carefully cleaned.</p> <p>It is best to apply conductive grease on the black PCR Saddle. Check the conductivity across the PCR and the PCR contact by using a multimeter.</p> <p>Apply silicone grease to the white PCR Saddle.</p>
	<p>Step 3</p> <p>Apply a small amount of silicone grease to the teeth of gears on the Drum Bearing Plate and the Inner surface of the Drum Bearing Plate.</p> <p>Screw on the OPC Drum Bearing Plate as shown in the photo using the screw provided with the waste hopper.</p>
	<p>Step 4</p> <p>Apply a small amount of conductive grease to the OPC Drum Pin.</p> <p>Then press the OPC Drum Pin into the end of the Triton waste hopper.</p>
	<p>Step 5</p> <p>Assemble the IC chip into the IC chip holder and heat seal in place at the arrowed positions as shown in the photo.</p> <p>The Assembly of T.P.E. CC1736 HP M4555MFP/M601/M602N/M602DN/M602X/M603/P4014/4015/4515 UNIVERSAL ENLARGED WASTE TONER HOPPER is now complete.</p>