





Instruction to make an OEM HP P1005/P1006 Standard Yield Cartridge / Starter Cartridge to use in the HP P1505 Printer by using CC1474 HP P1505 DRUM BEARING PLATE

	
<p>CC1474 HP P1505 DRUM BEARING PLATE</p>	<p>OEM HP P1006 Starter cartridge</p>

These instructions provide the information required to make an OEM HP P1005/P1006 Standard Yield Cartridge / Starter Cartridge to use in the HP P1505 Printer by using CC1474 HP P1505 DRUM BEARING PLATE. We use an OEM HP P1006 Starter Cartridge in this demonstration, although the same procedure is used on the Standard Yield Cartridge.

Please note using this conversion you cannot use a chip on the cartridge.

Procedures

	
<p>Step 1</p> <p>Cut the position activation boss on the Left Hand Side of OEM HP P1006 Cartridge's Waste Section.</p>	<p>Step 2</p> <p>Change the OEM HP P1006 Drum Bearing Plate with T.P.E. CC1474 HP P1505 DRUM BEARING PLATE. The Cartridge can now be used in the HP P1505 Printer.</p>

** Please note: PCB Trigger inside the printer could not be activated, as the position activation boss on the left of the waste section has been removed. The printer will still work without the PCB contact.

As the position activation boss on waste section is removed, please make sure the cartridge is installed properly into the printer. **