







**How to Install The T.P.E. CC1662 BROTHER HL-4140CN/4150CDN/4570CDW/4570CDWT/  
MFC-9460CDN/ 9560CDW/TN315/325/345 HIGH YIELD RESET LEVER AND SPRING**

<p><b>BROTHER HL-4140CN/4150CDN/4570CDW/4570CDWT/ MFC-9460CDN/9560CDW/STARTER/TN310/315/320/325/340/ 345/348 Toner Cartridge</b></p>	<p><b>CC1662 BROTHER HL-4140CN/4150CDN/4570CDW/ 4570CDWT/MFC-9460CDN/9560CDW/TN315/325/345 HIGH YIELD RESET LEVER AND SPRING</b></p>
	

**Procedures to convert a Starter or Standard Cartridge into a High Yield Cartridge**

	<p><b><u>Step 1</u></b> Unscrew the End Cap from the Starter (Standard Yield) toner cartridge.  Keep the end cap and small screws for reuse.</p>
	<p><b><u>Step 2</u></b> Install the T.P.E. HIGH YIELD RESET LEVER on to the shaft. The slot on the Reset Lever must be positioned correctly to avoid the idler gear as shown in the photo.</p>
	<p><b><u>Step 3</u></b> Install the T.P.E. Reset Lever Spring. Make sure the shorter tail of the Spring hooks onto the boss and the longer tail fits into a notch on the surface of the Reset Lever.  The teeth of the Reset Lever must engage with the idler gear after installed the spring for correct operation.</p>
	<p><b><u>Step 4</u></b> Install the OEM End Cap and fit the two screws but make sure the position of the Reset Lever does not move. If the lever does move, steps 2, 3 and 4 must be repeated. If the reset lever is not in the correct position, inserting the cartridge will not reset the printer.</p>